

## Release note for 2.4.3

### Notes

As of v2.4.2, RTTrPM Zone sending has been re-designed to be more efficient and in line with the rest of the RTTrP protocol. Please check the RTTrP GitHub for the latest packet specs or contact [support@blacktrax.ca](mailto:support@blacktrax.ca) for further information.

### Motive Dongle Date Requirement:

January 4<sup>th</sup> 2018

### Major changes:

- Auto apply feature to automatically Apply Changes at startup
- Improved dongle security

### Known issues:

- Changing the universe of a Fixture while it's actively tracking will not update its patch until a Chapter change

### Firmware Package Date:

February 2020

### Build Numbers:

BlackTrax: 2.4.3.12621

BTWYG: 2.42.52.217

Motive: 2.0.1.1.38436

### Server Version Requirement:

July 2016

### Device Manager Compatibility:

2.4.3


### Compatible with RTTrP Versions:

6

1.8.3

1.8.7

2.4.2



## Features and Fixes:

### ***New Feature***

- *A new option to auto apply BlackTrax on boot up*
  - *When the Main GUI boots up, and Tracker, Follower, and Monitor are all running BlackTrax will attempt to apply changes automatically*
    - *If BTWYG is set to open with the Portfolio, then BlackTrax will wait for WYG to connect before applying*
    - *If all modules are not running at boot up, auto apply will not attempt to connect*
  - *Off by default, the option is in System Configuration – System*

### ***Improvement***

- *Dongle security improvements*
  - *If your dongle is nearing expiry, a message will alert you 30 days in advanced*